



TDI110

Caple Integrated Tumble Dryer




Technical information




TDI110

Caple Integrated Tumble Dryer




Dimensions


Exploded View 1



Exploded View 2



Exploded View 3





TDI110 - Caple Sensor Integrated Tumble Dryer

Item	Part Code	Description	Qty
101	4213 092 25611	Motor & 8µf Capacitor Assembly	3
112	4213 092 08091	8µf Capacitor	3
125	4213 092 18601	Drive Belt	3
141	4213 076 35123	Mains Cable	3
142	4213 078 44613	Terminal Block	3
144	4213 092 41181	Earth Tab Assembly	3
196	4213 092 43481	Cabinet Assembly	1
199	4213 092 43491	Plinth Assembly	1
201	4213 077 08344	Door Seal	1
203	4213 092 45861	Complete Flatline Door Assembly	1
203a	4213 092 45901	Flatline Door Frame Assembly	1
211	4213 078 54732	Dreef 8 Position Rotary Switch - Dryers built up to serial No's beginning with 1227 .	1
211	4213 078 57641	Dreef 8 Position Rotary Switch - Dryers built with serial No's beginning 1228 and higher.	1
213	4213 092 09901	Neon Assembly	1
216	4213 092 44571	Switches & Bracket Assembly	1
227	4213 092 05521	Heating Element	3
228	4213 078 50161	Heat TOC	3
229	4213 078 48373	Thermostat (exhaust)	2
230	4213 078 56261	Thermostat (inlet)	3
232	4213 078 56423	Programmed PCB	1
248	4213 092 05251	Microswitch/Bracket Assembly	1 & 2
266	4213 092 25751	Drum Assembly	3
270	4213 092 05591	Drum Shaft/Bearing Kit	3
352	4213 092 56511	Timer Knob Assembly	1
353	4213 092 54281	Control Panel Assembly	1
355	4213 077 92382	Hinge Cover	1
359	4213 092 04751	Flatline Door Hinge Assembly	1
362	4213 077 44095	Window	1
363	4213 077 92284	Flatline Door Frame	1
363a	4213 077 92364	Flatline Door Handle	1
364	4213 075 13013	Latch Pivot	1
365	4213 075 70833	Latch Spring	1
366	4213 077 53413	Door Latch	1
367	4213 077 83571	Switch Strike	1
369	4213 075 70941	Loom Clip	1
370	4213 077 40992	Latch Guide	1
376	4213 092 45891	Front Panel Assembly	1




TDI110 - Caple Sensor Integrated Tumble Dryer

Item	Part Code	Description	Qty
386	4213 092 38311	Flat Top Cover Assembly	1
390	4213 074 50862	Gasket	3
391	4213 077 99991	Button	1
393	4213 077 40982	Flex Support Clip	3
395	4213 075 70971	Heater Wires Clip	3
399	4213 080 06619	Heater Support	3
400	4213 080 14551	Heater Plate	3
402	4213 080 06558	Access Panel	3
408	4213 077 47303	Cable Clamp	3
413	4213 092 37601	Back Panel Assembly	3
417	4213 070 12773	Brush Holder Support (RH)	1
418	4213 078 45023	Brush Assembly	1
419	4213 077 39503	Brush Holder	1
427	4213 078 45362	Motor Spring Clip	3
432	4213 080 0675A	Motor Mount Bracket	3
437	0312 002 02000	Extendable Rear Vent Kit (short)	2 & 3
438	4213 092 05731	Slip Ring Assembly	3
439	4213 092 05691	Sensing Strip Assembly	3
440	4213 092 17811	Banjo Assembly	2
441	4213 077 40952	Front Bearing (short)	2
442	4213 077 40942	Front Seal	2
444	4213 077 41248	Lifter	3
445	4213 077 40962	Front Bearing (long)	2
445a	4213 092 21171	Bearing Pads & Brush Seal Kit	2
446	4213 077 40896	Fan	2 & 3
447	4213 092 18081	Access Cover Assembly	2 & 3
448	4213 075 71162	Spring Clip (Fan)	2 & 3
454	4213 092 17821	Filter	2
456	4213 077 07991	Banjo Seal	2
458	4213 077 53502	Banjo Insert No 2 White	2
459	4213 077 53492	Banjo Insert No 1 White	2
463	4213 077 07711	Location Grommet	3
464	4213 077 41253	Slip Ring Insulator	3
465	4213 075 13141	Slip Ring	3
466	4213 075 70931	Ring Spring	3
467	4213 075 13152	Sensing Strip	3
468	4213 077 41176	Sensing Strip Clip	3
477	4213 074 81353	Ring Spring Plug	3

Not Shown On Exploded Views

4213 194 02471	User Instruction Booklet
4213 089 14741	Fittings Kit (Pair of Hinges, Door Stop, Spacers etc.)

Rotary Sensing Air Vented Dryer - Wiring Diagram



Component Code

TB	- Terminal Block
D-SW	- Door Switch
M	- Motor
CAP	- Capacitor
EX-TH	- Exhaust Thermostat
IN-TH	- Inlet Thermostat
HE	- Heater
ST-SW	- Start Switch
MAN TOC	- Manual Reset Cut-out
HE-SW	- Heat Switch

Wire Colour Code

A	- Black
B	- Brown
C	- Red
D	- Orange
E	- Yellow
F	- Green
G	- Blue
H	- Violet
J	- Grey
K	- White
N/A	- Pink