




# C210F/BLU


Caple Liberty Fan Oven Blue



TECHNICAL INFORMATION



3/1.AG



3/2.B



**CONTROL PANEL AND BODY**  
**OVENS: mod. C 210F/BLU, C 210F/GRN**

Ref. Table: 3/1.AG

<u>REF.</u>	<u>CODE</u>	<u>DESCRIPTION</u>
1.3	08318800D	Upper retainer trim - Mod. C 210F/BLU
=	083188007	Upper retainer trim - Mod. C 210F/GRN
1.5	35MF70201	Interior control panel
1.7	040011	Glass spacer
1.8	0311511	Glass fascia panel - Mod. C 210F/BLU
=	0311513	Glass fascia panel - Mod. C 210F/GRN
1.9	08309300D	Lower retainer trim - Mod. C 210F/BLU
=	083093007	Lower retainer trim - Mod. C 210F/GRN

Ref. Table: 3/2.B

<u>REF.</u>	<u>CODE</u>	<u>DESCRIPTION</u>
2.1	08318400D	Trim surround - Mod. C 210F/BLU
=	083184007	Trim surround - Mod. C 210F/GRN
2.2	411F719	Right side panel
2.3	411F721	Left side panel
2.4	411F711	Control panel shelter
2.5	411F723	Upper shelter
2.6	030092.1	Oven insulation
2.7	030028	Rear insulation
2.8	411F718	Rear panel
2.9	4216003Z	Insulation cross-piece
2.10	411F706	Bottom panel
2.11	053039	Seal
2.13	4216002Z	Lower switch shelter
2.14	085019	Spacer
2.15	450F71EM12	Oven cube



## OVEN DOOR

**OVENS: mod. C 210F/BLU, C 210F/GRN**

Ref. Table: 3/3.SA


<u>REF.</u>	<u>CODE</u>	<u>DESCRIPTION</u>
3.1	0311510	Outer glass - Mod. C 210F/BLU
=	0311512	Outer glass - Mod. C 210F/GRN
3.2	08318600D	Lower retainer trim - Mod. C 210F/BLU
=	083186007	Lower retainer trim - Mod. C 210F/GRN
3.3	037127	Handle
3.6	001108	Screw
3.7	373FF704K	Door skin
3.9	030057	Door insulation
3.10	063053	Hinge (male)
3.11	063025	Hinge (female)
3.12	0311000.1T	Inner glass
3.13	103205	Inner glass washer
3.14	001024	Screw
3.15	053084	Glass seal
3.16	003033	Washer
3.18	411F729	Insulation support
3.19	214021	Nut with clips
3.20	003035	Silicone washer
3.22	003041	Washer

## OVEN EQUIPMENT


**OVENS: mod. C 210F/BLU, C 210F/GRN**

Ref. Table: 3/4.B

<u>REF.</u>	<u>CODE</u>	<u>DESCRIPTION</u>
4.1	217291	Shelf support
4.4	217270.1	Wire shelf
4.9	217271	Wire shelf
4.10	217385	Grill-pan grid
4.11	48B5102K	Grill-pan
4.12	037144	Grill-pan grid handle



3/5.BB



3/6.CF


**FAN OVENS****OVENS: mod. C 210F/BLU, C 210F/GRN**

Ref. Table: 3/5.BB


<u>REF.</u>	<u>CODE</u>	<u>DESCRIPTION</u>
5.4	062053004	Grill element - 230 V
5.5	47AN601K	Fan diffuser
5.6	062057004	Fan element - 230 V
5.7	079008001F	Fan motor - 230 V
5.9	103085	Filter

Ref. Table: 3/6.CF

<u>REF.</u>	<u>CODE</u>	<u>DESCRIPTION</u>
6.1	2183442115	Control knob (Black)
6.2	050032	Switch
6.3	066072	Thermostat



3/7.BA



3/8.BA

**CLOCK****OVENS: mod. C 210F/BLU, C 210F/GRN**


Ref. Table: 3/7.BA

<u>REF.</u>	<u>CODE</u>	<u>DESCRIPTION</u>
7.7	2180002104	Knob (Black)
7.9	103155002	Knob ring (Black)
7.12	074031	Clock


**ELECTRICAL EQUIPMENT****OVENS: mod. C 210F/BLU, C 210F/GRN**

Ref. Table: 3/8.BA

<u>REF.</u>	<u>CODE</u>	<u>DESCRIPTION</u>
8.1	072003	Lamp holder
8.2	073013001	Lamp
8.8	054041	Cord
8.9	052001	Wire fastener
8.10	094162	Terminal bracket
8.11	051038	Terminal block
8.12	113734	Wiring
8.14	073030	Control lamp cover (Red)
8.15	073032	Control lamp (rectangular) L700
8.16	066057	Cut-off thermostat
–	110925	Instruction booklet



Oven switch diagram



**ELECTRIC DIAGRAM KEY**

- F1 Oven switch
- TM Oven thermostat
- TL Thermal overload
- PR Programmer
- LF Oven lamp
- G Grill element
- C Circular element
- V Fan
- S1 Thermostat pilot lamp
- M Terminal block
- T Earth connection



**C210F/BLU**

Cable Liberty Fan Oven Blue