



DI475

Caple Integrated Dishwasher

Technical information



101



102



103




104



105









106





107


108
















705




716




711



712



706




715

714




713

709



710





DI475 - Capele Integrated Dishwasher

Item	Part Code	Description	Qty
101	673000811024	Button	4
102	672000100012	Button spring	4
103	672000301723	Control panel cover sticker	1
104	673002102034	cover sticker	1
105	673003000119	SCREEN cover	1
107	673000404911	Control Panel	1
108	672001804073	OUTER DOOR	1
201	674010030017	DOOR SWICTH ASSEMBLY	1
202	672002200325	INNER DOOR	1
203	672002300037	FRICTION STRIP HOOKING	2
204	672002300049	FRICTION STRIP HOOKING CLAMPING	2
205	672001400059	LEFT HINGE	1
208	672001700002	DISPENSER BRACKET	2
209	674000800032	DISPENSER	1
210	672001400058	RIGHT HINGE	1
211	672001200070	HINGE join board	1
301	672001602006	LEFT SIDE PANEL	1
302	672001602007	RIGHT SIDE PANEL	1
303	673003100012	UPPER back support	1
305	673001300551	Cutlery shelf guider link stopper(back)	2
306	672001700023	Cutlery shelf guider(LEFT)	1
309	672001700039	basket guider supporter	4
310	673001300552	Cutlery shelf guider supporting holder	4
311	673001400295	Cutlery shelf guider supporter	4
313	673001300555	basket guider supporting holder	4
314	672000100093	anti-noise borad	1
315	673001300639	UPPER BASKET guider link stopper(back)	2
316	672001700025	UPPER BASKET guider(LEFT)	1
317	673001700125	door seal GASKET	1
319	672001400068	DOOR LOCK HOOK	1
320	673000102016	Back cover board	1
321	674000400015	head lamp	1
322	674000120002	head lamp link string	1
401	674000000186	Power cord	1
402	673001600058	AIR BREAKER NUT	1
403	673002700601	AIR BREAKER ASSEMBLY	1
404	674000700032	SOFTENER ASSEMBLY	1
405	673001300557	DRAIN pipe CLAMPING	4
408	673001300556	tub Support	2
409	673000103021	Base	1



DI475 - Capele Integrated Dishwasher

Item	Part Code	Description	Qty
410	673001000052	FRICION STRIP GUIDING	6
411	672002300036	FRICION STRIP	2
412	672000190028	DOOR SPRING	2
414	672001100016	adjust screw OF DOOR SPRING	2
417	673000101042	base cover	1
418	673001400210	foot	3
419	673002400192	pcb seat cover	1
420	673002400194	pcb seat	1
422	673001400211	Adjust pole	1
423	673001490013	FLOAT	1
425	673001400197	overflow switch seat	1
427	674010030006	overflow switch	1
428	674000300072	PRESSURE SWITCH	1
429	673001400083	power supply loom clamping	1
430	673000900354	DRAIN pipe	1
431	673001600068	SOFTENER nut	1
432	673002800161	SOFTENER cover	1
433	673001500106	SOFTENER rubber	1
504	673000900364	INNER PIPE	1
507	673001900023	water DISPENSER ASSEMBLY	1
510	673000310007	MIDDLE SPAYER	1
511	673000330005	LOWER SPRAYER	1
512	673001300548	LOWER SPRAYER seat	1
513	673002500112	PLASTIC FILTER	1
601	673001600057	SUMP NUT	1
602	673001500104	SUMP GASKET	1
603	673000900160	PVC pipe	1
604	673000900352	softener outlet pipe	1
607	673000701025	SUMP ASSEMBLY	1
608	673000900351	INNER DRAIN pipe	1
611	674000600154	Drainage pump	1
612	673002500125	main filter	1
613	673001300644	filter handle	1
614	673002500111	CYLINDR FILTER	1
615	673001500069	PUMP VIBRATION-PROOF PAD	1
616	674005600088	WASH PUMP ASSEMBLY	1
617	672002300038	motor holder	1
618	673001500111	PUMP GASKET	1
619	672000700031	940 CLAMPING	1
620	673001500115	HEATING ELEMENTS GASKET	1
621	674001100053	HEATING ELEMENTS ASSEMBLY	1
623	674010020008	WATER PRESSURE SWITCH ASSEMBLY	1
625	674000900053	Sensing device	1



DI475 - Caple Integrated Dishwasher

Item	Part Code	Description	Qty
627	673001500105	diverter GASKET	1
705	673003200026	Cutlery shelf ASSEMBLY	1
706	672000810039	UPPER BASKET ASSEMBLY	1
709	672000820008	LOWER BASKET ASSEMBLY	1
710	674000200041	Inlet hose assembly	1
711	674000101011	Wiring harness	1
712	673002200165	Salt filler	1
713	673000101047	basket Handle lid (front)	3
714	673000101048	basket Handle lid (back)	3
715	672000202125	BASKET HANDLE adhibit piece	2
716	672000301720	BASKET HANDLE adhibit piece I	1
106+421	674001001614	PCB	1
306-a	672001700024	Cutlery shelf guider(RIGHT)	1
316-a	672001700026	UPPER BASKET guider(RIGHT)	1

220-240V/50HZ



DI475

Cable Integrated Dishwasher

