



WI3123

Caple Classic 30cm Wine Cabinet




Technical Manual



WI3123

Caple Classic 30cm Wine Cabinet





WI3123

Caple Classic 30cm Wine Cabinet

Item	Part Number	Description	Quantity
1	DG11-45	Dry filter	1
2	DG2-14	Power cord	1
3	DG1-72	Compressor	1
4	DG13-199	Water tank	1
5	DG13-272-1	Electrical box	1
6	DG3-310-1	PCB board	1
7	DG13-268	Decorative nail	3
8	DG13-3148	Fixing bracket A	1
9	DG14-223-SR	Top right hinge	1
10	DG12-44-2	Evaporator	1
11	DG20-1	Clip	1
12	DG8-25-R	Sensor	1
13	DG7-48	Evaporator fan	1
14	DG13-158	Support pole	1
15	DG22-209	Air duct board	1
16	DG13-198	Sensor Cover - L = 300	1
17	DG8-30	Sensor	2
18	DG19-6	Fan cover	1
19	DG3-12-W	LED light	1
20	DG13-3239	Electrical box	1
21	DG3-005-2	Display board	1
22	DG13-3058	Display panel support	1
23	DG20-487	Control panel	1
24	DG13-1.2	Water tank	1
25	DG15-26-5	Wooden Shelf	1
26	DG23-375	Door	1
27	M160-049	Gasket	1
28	DG22-3490	Handle	1
29	DG22-3057	Axis	1
30	DG13-3155	Door axis spacer	1



WI3123

Caple Classic 30cm Wine Cabinet

Item	Part Number	Description	Quantity
31	DG15-27-3	Wooden Shelf	1
32	DG15-26-4	Wooden Shelf	4
33	DG14-212-SR	Lower right hinge	1
34	DG22-3201	Support bracket of front leg	1
35	DG13-3146	Cabinet leg	4
36	DG12-3	Condenser	1
37	DG7-33-BH	Condenser fan	1
38	DG22-3223	Fan bracket	1
39	DG13-83	Fan cover	2
40	DG12-58	Circumfluence pipe	1
41	DG22-39	Compressor bracket	1
Spare part	DG14-223-SL	Top left hinge	1
	DG14-212-SL	Lower left hinge	1
	DG22-3022	Bottom grill	1
	DG22-3301-1	Bottom grill	1
	DG22-3303-1	Grill support	2
	DG13-3154	Slider	2
	DG13-3151	Fixing bracket B	1

Wi6232 Wi6233
Wi3123 Wi3123GM Wi3124
Wi3150
WF333
Wi6140 Wi6141

