



WI6233

Caple Sense 60cm 2 Door 2 Zone Wine Cabinet




Technical Manual



WI6233

Caple Sense 60cm 2 Door 2 Zone Wine Cabinet





WI6233

Caple Sense 60cm 2 Door 2 Zone Wine Cabinet

Item	Part Number	Description	Quantity
1	DG12-37.1	Refrigerant valve	1
2	DG2-14	Power cord	1
3	DG7-47	Condenser fan	1
4	DG19-3	Fan cover	1
5	DG1-119	Compressor MG1080Y	1
6	DG13-403	Water tank	1
7	DG19-9	Condenser cover	1
	BZ7-131	Condenser anti-vibration gasket	1
8	DG3-301-3	PCB board	1
9	DG22-3334	Electrical box	1
10	DG14-190-SL	Top left hinge	1
11	DG14-190-SR	Top right hinge	1
12	DG12-44-2	Evaporator	2
13	DG7-48	Evaporator fan	2
14	DG22-209	Air duct board	2
15	DG19-6	Fan cover	2
16	DG13-198	Sensor cover	2
17	DG8-30	Sensor L=300	2
18	DG3-12-W	LED Light	2
19	DG13-3058	Installing support	2
20	DG20-487	Control panel	2
21	DG13-1.2	Humid box	2
22	M160-049	Gasket	2
23	DG22-3490	Handle	1
	DG22-3490	Handle	1
24	DG22-3057	Door axis	2
25	DG23-372-R	Door (Right)	1
26	DG23-372-L	Door (Left)	1
27	DG15-27-3	Wooden Shelf	2
28	DG15-26-4	Wooden Shelf	8
29	DG15-26-5	Wooden Shelf	2
30	DG13-3239	Electrical box	2



WI6233

Caple Sense 60cm 2 Door 2 Zone Wine Cabinet

Item	Part Number	Description	Quantity
31	DG14-212-SR	Lower right hinge	1
32	DG22-330	Support bracket of front leg	1
33	DG14-212-SL	Lower left hinge	1
34	DG12-91-2	Condenser	1
35	DG13-3146	Cabinet leg	4
36	DG12-113	Air-circulating pipe	2
37	DG22-331	Compressor bracket	1
38	DG11-46	Drier filter	1
39	DG13-3149	Fixing bracket A	1
40	DG8-25-R	Sensor	2
41	DG3-005-2	Display board	2
Spare part	DG22-3021	Bottom grill	1
	DG13-3154	Slider	2
	DG13-3152	Fixing bracket B	1

Wi6232 Wi6233
Wi3123 Wi3123GM Wi3124
Wi3150
WF333
Wi6140 Wi6141

