




C706G

Caple 4 Burner Gas Hob

Technical information

C706G

Caple 4 Burner Gas Hob






C706G - Caple 4 Burner Gas Hob

Item	Part Code	Description	Qty
1	211036140401	bottom plate	1
2	129010040102	screw M4x6	8
3	129010040402	S.S screw M4x12	1
4	129060010103	φ4 spring gasket	4
5	129020040101	M4 nut	2
6	1310200101	electric box	1
7	129010043501	S.S screw M4x8	2
8	129060040301	S.S.gasket	3
9	129020040103	S.S.nut M4	4
10	1410300401	528C thermocouple (350)	2
11	2111800101	clip for ignition pin	4
12	1410600204	ignition pin (470)	1
13	1110505001	50# burner basement	1
14	1110802001	50# nozzle	1
15	111216140951	gas tube for valve 1	1
16	1110491304	valve 1	1
17	129010040201	screw M4x8	4
18	2111109702	clip for gas tube	1
19	129060010103	spring gasket	8
20	1290100444	screw M4x18	8
21	1110491301	valve 4	1
22	1110491303	valve 2	2
23	111106140103	gas inlet tube	1
24	171002	gasket	1
25	171001	elbow	1
26	111216140954	gas tube for valve 4	1
27	1410600202	ignition pin(220)	1
29	111216140953	gas tube for valve 3	1
30	1110507001	70# burner basement	2
31	1110802002	70# nozzle	2
32	1410300402	528C thermocouple (500)	1
33	1410600201	ignition pin(120)	1
34	111080204801	120# nozzle	1
35	111216140952	gas tube for valve 2	1
36	1110512002	120# burner basement	1
37	1410300304	516C thermocouple (500)	1
38	1410600103	ignition pin(360)	1
39	211026143250	Panel	1
40	1110605001	50# burner	1
41	1110705002	50# burner cap	1
42	28211413107201	knob	4
43	129010041201	S.S. screw M4x8	10
44	1110607001	70# burner	2
45	1110707002	70# burner cap	2



C706G - Caple 4 Burner Gas Hob

Item	Part Code	Description	Qty
46	111096140121	pan suport	1
47	1110712023	120# central burner cap	1
48	1110712024	120# external burner cap	1
49	1110612002	120# burner	1
50	129020040105	nut	2
51	1410800202	impulse device	1
52	2119900707	mica gasket	1
53	129010040401	screw M4x12	2



C744G C706G C786G