



C789G

Caple 87cm wide gas on glass hob






Technical Manual



C789G

Caple 87cm wide gas on glass hob





C789G

Caple 87cm wide gas on glass hob

Item	Part Number	Description	Quantity
1	211039155451	Bottom Plate	1
2	129010040102	Screw M4*6	8
3	129010044101	Screw M4*16	10
4	129010043501	Screw M4*8 (Steel)	10
5	2111109701	Gas Tube bracket	1
6	111109151196	Main Gas Tube	1
7	1110491384	Valve 1	1
8	111209151655	Alu. Tube 5	1
9	1110491382	Valve 3	1
10	111209151654	Alu. Tube 4	1
11	1110505004	Burner Base ϕ 50	1
12	111080307401	Jet #50	1
13	1410301810	Thermostat 350	2
14	1410601311	Ignition 200L	1
15	1110510004	Burner Base ϕ 100	1
16	1410301811	Thermostat 550	2
19	111080307201	Jet #100	1
20	2111800101	Ignition clip	5
21	171001	elbow	1
22	1311300601	Gasket	2
23	2111400101	Gas Tube Clip	1
24	211569150601	Alu. Decoration plate	1
25	131110120202	Sealing Ring for knob	5
26	131010015606	Knob	5
27	GPAC789G	Glass Panel	1
28	211190501612	Water tray for Auxiliary burner	1
29	1110605005	Burner ϕ 50	1
30	1110705011	Burner Cap ϕ 50	1
31	111099151801	Side Pan Support	2
32	1110710011	Burner Cap ϕ 100	1
33	1110610005	Burner ϕ 100	1
34	211191001312	Water tray for Rapid burner	1
35	211191205611	Water tray for Wok burner	1
36	1110612008	Burner ϕ 120	1
37	111071203101	External burner cap ϕ 120	1
38	111071203001	Central Burner Cap ϕ 120	1
39	111099151802	Middle Pan Support	1
40	1110707011	Burner Cap ϕ 70	2



C789G

Caple 87cm wide gas on glass hob

Item	Part Number	Description	Quantity
41	1110607005	Burner ϕ 70	2
42	1290100436	M4x14 screw	16
43	211190701612	Water tray for Semi-Rapid burner	2
44	111080307301	Jet #70	2
45	1410601310	Ignition 800L	2
46	1110507004	Burner Base ϕ 70	2
47	1410601313	Ignition 570L	2
48	1410301802	Thermostat 450	1
49	111080307101	Jet #120	1
50	1110512004	Burner Base ϕ 120	1
51	111209151653	Alu. Tube 3	1
52	1110491381	Valve 4	1
53	1110491383	Valve 2	2
54	111209151652	Alu. Tube 2	1
55	111209151651	Alu. Tube 1	1
56	2112000462	Burner Support #70	2
57	2112000202	Burner support #120	1
58	1290100443	Screw M4x10	2
59	2112000460	Burner support #100	1
60	2112000463	Burner Support #50	1
61	129020040102	M4 nuts	2
62	141080020401	impulse	1
63	216001	Mica pads	
65	2111007002	Metal Ring for semi rapid burner	2
66	2111010002	Metal Ring for rapid burner	1
67	2111012001	Metal Ring for wok burner	1
68	2111005002	Metal Ring for Auxiliary Burner	1
72	1290202001	fixing nut for ignition #120	1
74	2112370501	Insulation board	1
75	1310200301	Electric box	1
77	129010043504	M4x8 screw (Brass)	2

