



C2105


Caple Sense Touch Control Single Oven



Technical Manual



C2105  
Caple Sense Touch Control Single Oven





C2105

Caple Sense Touch Control Single Oven

Item	Product code	Description	Additional Info	Quantity
1	142101500201	Power cord		1
2	1421600101	Power box		1
3	2121600103	Rear cover		1
4	142090020303	Circulating fan motor		1
6	1420900305	Synchronous motor	Rotisserie Motor	1
5	1421200107	Thermostat 125°C		1
7	2121500601	Bracket of convection motor		1
8	1420700117	Halogen lamp		2
9	1920100225	Rear isolation cotton		1
10	1420500125	Top heater		1
11	1420900218	Motor (cooling fan)		1
12	2121400201	Top cover		1
13	1422100115	Power board for PCB		1
14	2126700104	Cooling cover component		1
15	2121200501	Top Panel		1
16	2126800701	Vent		1
17	1920100122	Top isolation cotton		1
18	1320400101	Holders		2
19	2121000302	Right side panel		1
20	212090051701	Cavity assembly		1
21	1420500309	Circle heater		1
22	212030080103	Fan cover		1
23	212020014701	Door frame		1
24	2126500207	Right hinge bracket		1
25	1320200901	Door seal		1
26	1421500123	Display		1
27	EB-67ERCD9-S-05-01	Control Panel component	Glass for Control Panel	1
28			Display bracket	1
29			Aluminium Strips	2
31	1120100359	Inner glass		1
32	2127400702	Fixing plate for Middle Glass		2
33	1120100220	Middle glass		1
34	2127401807	Door bracket		1
35	1123500207	Right buckle for door bracket		1



C2105

Caple Sense Touch Control Single Oven

Item	Product code	Description	Additional Info	Quantity
30	EB-67ERCD9-S-06-01-1	Outer door glass component	Outer glass	1
36			Left door bracket	1
37			Right door bracket	1
38			Spring for glass bracket	2
39			Clip glass bracket	1
46			Aluminium strip	1
40			112240031403	Handle
41	2126600304	Fixing plate for right outer door hinge assembly		1
42	1320600124	Plastic gasket for right door hinge bracket		1
43	1320600123	Plastic gasket for left door hinge bracket		1
44	2126600303	Fixing plate for left outer door hinge assembly		1
45	1120400706	Soft Hinge		2
47	1123500208	Left buckle for door bracket		1
48	1320600115	Plastic gasket for inner door glass		4
49	2126500107	Left hinge bracket		1
50	1420500215	Bottom heater		1
51	2121700501	Bottom heater plate		1
52	2121300103	Insulation plate		1
53	2121800603	Bottom plate		1
54	2126100105	Fixing Screw (Side shelves)		4
55	1122000103	Fixing Plate for Side shelves		4
56	1121800107	Upper Probe		1
57	2121100303	Left side panel		1
58	EB-67ERCD-16/17	Side shelves	Left side shelf	1
			Right side shelf	1



C2105

Caple Sense Touch Control Single Oven

Item	Product code	Description	Additional Info	Quantity
59	212210010404	Food tray		1
60	EB-67ECD6-L-06A/B	Full extension runner		2
61	1120500122	Big grill rack		2
62	1120500203	Small grill rack		1
63	1121900102	Hook		1
64	1121900103	Hook ring		1
65	2123800102	Tray Handle		1
66	2120401001	Catalytic side panel		2
67	1122600111	Rotisserie Accessories		1
	EB67ERC9S0611	Complete door		1