



C2105GM

Caple Touch Control Single Oven Gun Metal




Technical Information



C2105GM

Caple Touch Control Single Oven Gun Metal





C2105GM

Caple Touch Control Single Oven Gun Metal

Item	Product code	Description	Additional Info	Quantity
1	142101500201	Power cord		1
2	1421600101	Power box		1
3	2121600103	Rear cover		1
4	142090020303	Circulating fan motor		1
6	1420900305	Synchronous motor	Rotisserie Motor	1
5	1421200107	Thermostat 125°C		1
7	2121500601	Bracket of convection motor		1
8	1420700117	Halogen lamp		2
9	1920100225	Rear isolation cotton		1
10	1420500125	Top heater		1
11	1420900218	Motor (cooling fan)		1
12	2121400201	Top cover		1
13	1422100115	Power board for PCB		1
14	2126700104	Cooling cover component		1
15	2121200501	Top Panel		1
16	2126800701	Vent		1
17	1920100122	Top isolation cotton		1
18	1320400101	Holder		2
19	2121000302	Right side panel		1
20	212090051701	Cavity assembly		1
21	1420500309	Circle heater		1
22	212030080103	Fan cover		1
23	212020014701	Door frame		1
24	2126500207	Right hinge bracket		1
25	1320200901	Door seal		1
26	1421500123	Display		1
27	ECD9GMCP	Gun Metal Control Panel component	Glass for Control Panel	1
28			Display bracket	1
29			Gun Metal Frame	1
31	1120100359	Inner glass		1
32	2127400702	Fixing plate for Middle Glass		2
33	1120100220	Middle glass		1
34	2127401807	Door bracket		1
35	1123500207	Right buckle for door bracket		1



C2105GM

Caple Touch Control Single Oven Gun Metal

Item	Product code	Description	Additional Info	Quantity
30	67GMDOG	Outer door glass component	GM Door Frame	1
36			Clip for glass bracket	2
37			Right door bracket	1
38			Spring for glass bracket	1
39			Left door bracket	1
46			Tinted Outer glass	1
40	112240031403	Handle		1
41	2126600304	Fixing plate for right outer door hinge assembly		1
42	1320600124	Plastic gasket for right door hinge bracket		1
43	1320600123	Plastic gasket for left door hinge bracket		1
44	2126600303	Fixing plate for left outer door hinge assembly		1
45	1120400706	Soft Hinge		2
47	1123500208	Left buckle for door bracket		1
48	1320600115	Plastic gasket for inner door glass		4
49	2126500107	Left hinge bracket		1
50	1420500215	Bottom heater		1
51	2121700501	Bottom heater plate		1
52	2121300103	Insulation plate		1
53	2121800603	Bottom plate		1
54	2126100105	Fixing Screw (Side shelves)		4
55	1122000103	Fixing Plate for Side shelves		4
56	1121800107	Upper Probe		1
57	2121100303	Left side panel		1
58	EB-67ERCD-16/17	Side shelves	Left side shelf	1
			Right side shelf	1




C2105GM

Caple Touch Control Single Oven Gun Metal

Item	Product code	Description	Additional Info	Quantity
59	212210010404	Food tray		1
60	EB-67ECD6-L-06A/B	Full extension runner		2
61	1120500122	Big grill rack		2
62	1120500203	Small grill rack		1
63	1121900102	Hook		1
64	1121900103	Hook ring		1
65	2123800102	Tray Handle		1
66	2120401001	Catalytic side panel		2
67	1122600111	Rotisserie Accessories		1
	GMCD67D9	Complete door		1

# C2105GM

## Circuit Schematics



Main metal enclosure  
and all heating elements metal sheath