



C2239

Caple Classic Pyro Oven




Technical Manual



C2239

Caple Classic Pyro Oven





C2239

Caple Classic Pyro Oven

Item	Part Number	Descriptions	Remarks	Quantity
1	142101500201	Power cord		1
2	1421600101	Power box		1
3	2121600103	Rear cover		1
4	142090020303	Circulating fan motor		1
5	1421100111	Thermostat 90°C		1
6	1421100203	Thermostat 172°C		1
7	2121500601	Bracket of convection motor		1
8	1420700113	Halogen lamp		2
9	1920100229	Rear isolation cotton		1
10	1420500129	Top heater		1
11	1420900220	Motor (cooling fan)		1
12	2121400901	Top cover		1
13	1421100112	Thermostat 145°C		1
14	2126700112	Cooling cover component		1
15	2127500501	Top Panel		1
16	2126800701	Vent		1
17	1920100123	Top isolation cotton		1
18	1320400101	Holder		2
19	2121000302	Right side panel		1
20	2.1209E+11	Cavity assembly		1
21	1420500407	Circle heater		1
22	212030080102	Fan cover		1
23	212020014901	Door frame		1
24	2126500207	Right hinge bracket		1
25	1320200902	Door seal		1
26	2123410004	Timer bracket		1
27	1421500134	Timer		1
28	C2239CPC	Control Panel component	Glass for Control Panel	1
			Glass bracket	2
			Stainless steel Frame	2
29	132010015101	Knobs		2
30	1320600105	Cushion for control panel		2
31	2127700501	Fixing plate for power board		1
32	1422100159	Power board		1



C2239

Caple Classic Pyro Oven

Item	Part Number	Descriptions	Remarks	Quantity
33	1120100360	Inner glass		1
34	1120100221	Middle glass 1		1
35	1120100220	Middle glass 2		1
36	2127401807	Door bracket		1
35	1123500207	Right buckle for door bracket		1
37	C2239OGC	Outer door glass component	Left door bracket	1
			Right door bracket	1
			Outer glass	1
			Stainless steel Strip	1
38	1122400314	Handle		1
39	2126600304	Fixing plate for right outer door hinge assembly		1
40	1320600124	Plastic gasket for right door hinge bracket		1
41	1320600123	Plastic gasket for left door hinge bracket		1
42	2126600303	Fixing plate for left outer door hinge assembly		1
43	1120400703	Hinge		2
44	1990200210	Seal for middle glass		1
45	2126500107	Left hinge bracket		1
46	1420500215	Bottom heater		1
47	2121700501	Bottom heater plate		1
48	2121300103	Insulation plate		1
49	2121800603	Bottom plate		1
51	2126100105	Fixing Screw(Side shelves)		4
50	1122000103	Fixing Plate for Side shelves		4
52	1121800102	Upper Probe		1
53	2121100804	Left side panel		1
54	1120500701	Side shelves	Left side shelf	1
	1120500702		Right side shelf	1
55	212210010405	Food tray		1
56	EB-67ECD6-L-06A/B	Full extension full extension runner		2
57	1120500122	Big grill rack		2
59	1124100102	Filter		1
60	2128700102	Installation box for lock		1
61	1124000101	Lock		1
62	1120500203	Small grill rack		1
63	1124300202	plastic limit block for door	1124400102 Fan blade GMCD67D12P Complete door	
64	1422200102	easytronic		
65	1422700103	Function selector		