



C2403GM

Caple 14 Function Pyro Oven Gunmetal




Technical Manual



C2403GM

Caple 14 Function Pyro Oven Gunmetal





C2403GM

Caple 14 Function Pyro Oven Gunmetal

Item	Part Number	Description	Remarks	Quantity
1	142101500201	Power cord		1
2	1421600101	Power box		1
3	2121600103	Rear cover		1
4	142090020303	Circulating fan motor		1
5	1421100111	Thermostat 90°C		1
6	1421100203	Thermostat 172°C		1
7	2121500601	Bracket of convection motor		1
8	1420700117	Halogen lamp		2
9	1920100229	Rear isolation cotton		1
10	1420500129	Top heater		1
11	1420900220	Motor (cooling fan)		1
12	2121400901	Top cover		1
13	1421100112	Thermostat 145°C		1
14	2126700112	Cooling cover component		1
15	2127500501	Top Panel		1
16	2126800701	Vent		1
17	1920100123	Top isolation cotton		1
18	1320400101	Holder		2
19	2121000302	Right side panel		1
20	2.1209E+11	Cavity assembly		1
21	1420500407	Circle heater		1
22	212030080102	Fan cover		1
23	212020014901	Door frame		1
24	2126500207	Right hinge bracket		1
25	1320200902	Door seal		1
26	1422100177	Display		1
27	GMCP2402	GM Control Panel component	Glass for Control Panel	1
28			Display bracket	1
29			GM Frame	1
30	2121300105	Insulation board for holder		2
31	2127700501	Fixing plate for power board		1
32	1422100176	Power board		1
33	1120100360	Inner glass		1
34	1120100221	Middle glass 1		1
35	1120100220	Middle glass 2		1



C2403GM

Caple 14 Function Pyro Oven Gunmetal

Item	Part Number	Description	Remarks	Quantity
36	2127401807	Door bracket		1
35	1123500207	Right buckle for door bracket		1
37	67D8GMDOG	GM Outer door glass component	Right door bracket	1
38			GM Door Frame	1
39			Outer glass	1
46			Left door bracket	1
38	112240031403	Handle		1
41	2126600304	Fixing plate for right outer door hinge assembly		1
42	1320600124	Plastic gasket for right door hinge bracket		1
43	1320600123	Plastic gasket for left door hinge bracket		1
44	2126600303	Fixing plate for left outer door hinge assembly		1
45	1120400703	Hinge		2
47	1123500208	Left buckle for door bracket		1
49	2126500107	Left hinge bracket		1
50	1420500215	Bottom heater		1
51	2121700501	Bottom heater plate		1
52	2121300103	Insulation plate		1
53	2121800603	Bottom plate		1
54	2126100105	Fixing Screw(Side shelves)		4
55	1122000103	Fixing Plate for Side shelves		4
56	1121800102	Upper Probe		1
57	2121100804	Left side panel		1
58	1120500701	Side shelves	Left side shelve	1
58	1120500702		Right side shelve	1
59	212210010405	Food tray		1
60	EB-67ECD6-L-06A/B	Full extension full extension runner		2
61	1120500122	Big grill rack		2
62	1120500203	Small grill rack		1
63	1124100102	Filter		1
64	2128700102	Installation box for lock		1
65	1124000101	Lock		1

GMCD67D8P

Complete door