



C2600

Caple Sense Premium Oven Black




Technical Manual



C2600

Cable Sense Premium Oven Black





C2600

Caple Sense Premium Oven Black

Item	Part Number	Description	Note	Additional Info	Quantity
1	142101503001	Power cord			1
2	1421600101	Power box			1
3	2121600103	Rear cover			1
4	1420900231	Circulating fan motor			1
5	1421100119	Thermostat 90°C			1
6	1421100203	Thermostat 172°C			1
7	2121500601	Bracket of convection motor			1
8	1420700117	Halogen lamp			2
9	1920100229	Rear isolation cotton			1
10	1420500129	Top heater			1
11	142090022001	Motor (cooling fan)			1
12	2121400901	Top cover			1
13	1421100112	Thermostat 145°C			1
14	2126700112	Cooling cover component			1
15	2127500501	Top Panel			1
16	2126800701	Vent			1
17	1920100123	Top isolation cotton			1
18	1320400101	Holder			2
19	2121000807	Holder			1
20	212090053001	Right side panel			1
21	1420500407	Circle heater			1
22	212030080304	Cavity assembly			1
23	212020015601	Fan cover			1
24	2126500207	Door frame			1
25	1320200905	Door seal			1
26	CPA2600	Control Panel component for C2601	26	1321500107 - TFT bracket	1
			28	11201014090 - Glass for Control Panel	1
			30	1121000102 - Glass connector	4
			38	212940010102 - Aluminium Strips	2



C2600

Caple Sense Premium Oven Black

Item	Part Number	Description	Note	Additional Info	Quantity
27	1422100178	TFT Display			1
58-1	1120500701	Left side shelve			1
31	2127700501	Fixing plate for power board			1
32	1422100179	Power board			1
33	1120100360	Inner glass			1
34	1120100221	Middle glass 1 Low-E			1
35	1120100220	Middle glass 2			1
36	2127401806	Top Door bracket			1
39	ODGA2401	Door Outer glass Assembly	37	212740181001 - Right door bracket	1
			38	212940010102 - Aluminium Strips	1
			39	112010013320 - Outer glass	1
			46	212740181101 - Left door bracket	1
40	1122400314	Handle			1
41	2126600304	Fixing - right door hinge assy			1
42	1320600124	Plastic gasket - right hinge			1
43	1320600123	Plastic gasket - left hinge			1
44	2126600303	Fixing - left door hinge assy			1
45	1120400703	Hinge			2
47	2127400702	Bracket for middle glass			2
48	1990200210	Seal for middle glass			1
49	2126500107	Left hinge bracket			1
50	1420500215	Bottom heater			1
51	2121700501	Bottom heater plate			1
52	2121300103	Insulation plate			1
53	2121800603	Bottom plate			1
54	2126100105	Fixing Screw(Side shelves)			4
55	112200010401	Fixing Plate for Side shelves			4
56	1121800102	Upper Probe			1
57	212110080401	Left side panel			1



C2600

Caple Sense Premium Oven Black

Item	Part Number	Description	Note	Additional Info	Quantity
58-2	1120500702	Right side shelve			1
59	212210011902	Food tray			1
60-1	1123600103	Full extension runner Left			2
60-2	1123600104	Full extension runner Right			2
61	1120500122	Big grill rack			2
62	1120500203	Small grill rack			1
63	1124100102	Filter			1
64	2128700102	Installation box for lock			1
65	1124000101	Lock			1
66	2123800102	Tray handle			1
67	2121300108	Isolation plate for TFT			1
68	1420900301	Synchronous motor			1
69	1121800201	Meat Probe assembly			1
70	1220100124	Meat Probe nut			1
71	1121800202	Socket for Meat Probe			1
72	1321500201	Socket cover			1
73	132140010501	WIFI Box(Bottom)			1
74	1422900107	WIFI Chip			1
75	132140010402	WIFI Box(Cover)			1
76	1121900102	Hook			1
77	1121900103	Hook ring			1
N/A	SCD67D8P	Complete door			1
N/A	1122600111	Rotisserie			1