



C2600SS

Caple Sense Premium Oven Stainless Steel




Technical Manual



C2600SS

Cable Sense Premium Oven Stainless Steel





C2600SS

Caple Sense Premium Oven Stainless Steel

Item	Part Number	Description	Note	Additional Info	Quantity
1	142101503001	Power cord			1
2	1421600101	Power box			1
3	2121600103	Rear cover			1
4	1420900231	Circulating fan motor			1
5	1421100119	Thermostat 90°C			1
6	1421100203	Thermostat 172°C			1
7	2121500601	Bracket of convection motor			1
8	1420700117	Halogen lamp			2
9	1920100229	Rear isolation cotton			1
10	1420500129	Top heater			1
11	142090022001	Motor (cooling fan)			1
12	2121400901	Top cover			1
13	1421100112	Thermostat 145°C			1
14	2126700112	Cooling cover component			1
15	2127500501	Top Panel			1
16	2126800701	Vent			1
17	1920100123	Top isolation cotton			1
18	1320400101	HOLDERS			2
19	2121000807	HOLDERS			1
20	212090053001	Right side panel			1
21	1420500407	Cavity assembly			1
22	212030080304	Circle heater			1
23	212020015601	Fan cover			1
24	2126500207	Door frame			1
25	1320200905	Door seal			1
26	CPA2600SS	Control Panel component for C2600SS	26	1321500107 - TFT bracket	1
			28	11201014091 - Glass for Control Panel	1
			30	1121000102 - Glass connector	4
			38	2200100202 - SS Frame	1
27	1422100178	TFT Display			1
58-1	1120500701	Left side shelve			1
31	2127700501	Fixing plate for power board			1
32	1422100179	Power board			1
33	1120100360	Inner glass			1
34	1120100221	Middle glass 1 Low-E			1
35	1120100220	Middle glass 2			1
36	2127401806	Top Door bracket			1



C2600SS

Caple Sense Premium Oven Stainless Steel

Item	Part Number	Description	Note	Additional Info	Quantity
39	ECD12SSODC	SS Outer door glass component	37	212740181001 - Right door bracket	1
			38	212220302701 - SS Door Frame	1
			39	11201001332301 - Outer glass	1
			46	212740181101 - Left door bracket	1
40	1122400314	Handle Silver			1
41	2126600304	Fixing - right door hinge assy			1
42	1320600124	Plastic gasket - right hinge			1
43	1320600123	Plastic gasket - left hinge			1
44	2126600303	Fixing - left door hinge assy			1
45	1120400703	Hinge			2
47	2127400702	Bracket for middle glass			2
48	1990200210	Seal for middle glass			1
49	2126500107	Left hinge bracket			1
50	1420500215	Bottom heater			1
51	2121700501	Bottom heater plate			1
52	2121300103	Insulation plate			1
53	2121800603	Bottom plate			1
54	2126100105	Fixing Screw(Side shelves)			4
55	112200010401	Fixing Plate for Side shelves			4
56	1121800102	Upper Probe			1
57	212110080401	Left side panel			1
58-2	1120500702	Right side shelve			1
59	212210011902	Food tray			1
60-1	1123600103	Full extension runner Left			2
60-2	1123600104	Full extension runner Right			2
61	1120500122	Big grill rack			2
62	1120500203	Small grill rack			1
63	1124100102	Filter			1
64	2128700102	Installation box for lock			1
65	1124000101	Lock			1
66	2123800102	Tray handle			1
67	2121300108	Isolation plate for TFT			1
68	1420900301	Synchronous motor			1
69	1121800201	Meat Probe assembly			1
70	1220100124	Meat Probe nut			1



C2600SS

Caple Sense Premium Oven Stainless Steel

Item	Part Number	Description	Note	Additional Info	Quantity
71	1121800202	Socket for Meat Probe			1
72	1321500201	Socket cover			1
73	132140010501	WIFI Box(Bottom)			1
74	1422900107	WIFI Chip			1
75	132140010402	WIFI Box(Cover)			1
76	1121900102	Hook			1
77	1121900103	Hook ring			1
N/A	SSCD67D12P	Complete door			1
N/A	1122600111	Rotisserie			1