



C2601BG

Caple Sense Premium Oven




Technical Manual



C2601BG

Cable Sense Premium Oven





C2601BG

Caple Sense Premium Oven

Item	Part Number	Description	Additional Info
1	142101503001	Power cord	
2	1421600101	Power box	
3	2121600103	Rear cover	
4	1420900231	Circulating fan motor	
5	1421100119	Thermostat 90°C	
6	1421100203	Thermostat 172°C	
7	2121500601	Bracket of convection motor	
8	1420700117	Halogen lamp	
9	1920100229	Rear isolation cotton	
10	1420500129	Top heater	
11	142090022001	Motor (cooling fan)	
12	2121400901	Top cover	
13	1421100112	Thermostat 145°C	
14	2126700112	Cooling cover component	
15	2127500501	Top Panel	
16	2126800701	Vantile	
17	1920100123	Top isolation cotton	
18	1320400101	Holdings	
19	2121000807	Right side panel	
20	212090053001	Cavity assembly	
21	1420500407	Circle heater	
22	212030080304	Fan cover	
23	212020015601	Door frame	
24	2126500207	Right Hinge Bracket	
25	1320200905	Door seal	
26	CPA2601BG	Control Panel component	TFT bracket
			Light tinted Glass for Control Panel
			Glass connector
27	1422100178	TFT Display	
58-1	1120500701	Left side shelve	
31	2127700501	Fixing plate for power board	
32	220208005007002	Power board	
33	1120100360	Inner glass	
34	1120100221	Middle glass 1 Low-E	
35	1120100220	Middle glass 2	
36	2127401806	Top Door bracket	
39	ODGC2401BG	BG Outer door glass component	Right door bracket
			BG Outer glass
			Left door bracket



C2601BG


Caple Sense Premium Oven

Item	Part Number	Description	Additional Info	Quantity
40	112240031403	Handle (Black)		1
41	2126600304	Fixing plate for right outer door hinge assembly		1
42	1320600124	Plastic gasket for right door hinge bracket		1
43	1320600123	Plastic gasket for left door hinge bracket		1
44	2126600303	Fixing plate for left outer door hinge assembly		1
45	1120400703	Hinge		2
47	2127400702	Bracket for middle glass		2
48	1990200210	Seal for middle glass		1
49	2126500107	Left hinge bracket		1
50	1420500215	Bottom heater		1
51	2121700501	Bottom heater plate		1
52	2121300103	Insulation plate		1
53	2121800603	Bottom plate		1
54	2126100105	Fixing Screw (Side shelves)		4
55	112200010401	Fixing Plate for Side shelves		4
56	1121800102	Upper Probe		1
57	212110080401	Left side panel		1
58-2	1120500702	Right side shelfe		1
59	212210011902	Food tray		1
60-1	1123600103	Full extension runner (Left)		2
60-2	1123600104	Full extension runner (Right)		2
61	1120500122	Big grill rack		2
62	212210012102	Enamel grill rack		1
63	1124100102	Filter		1
64	2128700102	installation box for lock		1
65	21020804301002	Lock(Micro-Switch + door Lock)		1
66	2123800102	Tray handle		1
67	2121300108	Isolation plate for TFT		1
68	1420900301	Synchronous motor		1
69	1121800201	Meat Probe assembly		1
70	1220100124	Meat Probe nut		1
71	1121800202	Socket for Meat Probe		1
72	1321500201	Socket cover		1
73	132140010501	WIFI Box(Bottom)		1
74	1422900107	WIFI Chip		1
75	132140010402	WIFI Box(Cover)		1
76	1121900102	Hook		1
77	1121900103	Hook ring		1
78	21020806206004	Air fry tray		1

CDAC2601BG Complete door

1122600111 Rotisserie

C2601 Wiring Diagram



C2601** – Wiring Diagram

