



C2902BG

Caple 90cm Touch Control Oven




Technical Manual



C2902BG

Caple 90cm Touch Control Oven





C2902BG

Caple 90cm Touch Control Oven

Item	Part Number	Description	Additional Info	Quantity
1	142101500201	Power cord		1
2	1421600101	Power box		1
3	2121603801	Back Panel		1
4	142090020101	Circulating fan motor		1
5	2125700101	Top heater plate		1
6	1920100226	Rear isolation cotton		1
7	1420700113	Lamp		2
8	1420500128	Top heater		1
9	2121400102	Top Panel		1
10	1420900143	Cooling fan		1
11	212670030401	Vantile		1
12	1920100118	Upper isolation cotton		1
13	212540010301	Top and Bottom frame		2
14	2125500101	Synchronous motor plate		1
15	1420900305	Synchronous motor		1
16	2125600101	Plate for thermostat		1
17	1421200207	Thermostat 110°C		1
18	212520010101	Right frame		1
19	2121000103	Right panel		1
20	1220100102	Aluminium casing		2
21	212090160101	Cavity		1
22	2128400103	Rivet Nuts		2
23	1220100117	Fixing screws for side shelves		2
24	1420500304	Circle heater		1
25	1220100123	Heat shield studs		4
26	212030020101	Fan cover		1
27	1220100104	Nuts for fan cover		4
28	2126500301	Hinge bracket		2
29	21202002101	Door frame		1
30	1320600126	Plastic cushion for inner glass		1
31	1422100139	Timer		1
32	2124920001	Bracket for Control panel		1
36	CPA2902BG	Control Panel components	Timer box	1
			Decorative frame for control panel	1
			Glass Panel	1
37	1120100354	Inner glass		1
38	2127400702	Fixing plate for Middle Glass		2
39	1120100218	Middle Glass		1



C2902BG

Caple 90cm Touch Control Oven

Item	Part Number	Description	Additional Info	Quantity
40	212740190101	S.S. Door bracket		1
41	1123500207	Right buckle for door bracket		1
42	2127401803	Spring for glass bracket		2
44	1120400703	Outer hinge		2
45	ODGC2902BG	Outer glass components	Left door bracket	1
			Outer glass	1
			Right door bracket	1
47	2126600301	Fixing plate for left outer door hinge assembly		1
48	1320600123	Plastic gasket for left door hinge bracket		1
49	112240031403	Handle(Black)		1
51	1320600124	Plastic gasket for right door hinge bracket		1
54	1123500208	Left buckle for door bracket		1
55	1320200105	Door Seal		1
56	1422100140	Power board for PCB		1
57	2127300108	Cavity support		1
58	2121100103	Left panel		1
59	1123900101	Holder		2
60	212530010501	Left frame		1
61	1420500216	Bottom Heater		1
62	2123900201	Fixing plate for bottom heater		1
63	2121700601	Clips for bottom heater		2
64	2121300104	Isolated plate		1
65	1121800107	Probe		1
66	2121800202	Bottom panel		1
67	1120500801	Side shelves		2
68	EB-67ECD6-L-06A/B	Full extension runner		2
69	1120500123	Big rack		2
70	1120500206	Small rack		1
71	1122600112	Rotisserie components		1
72	212590010101	Rotisserie plate A		2
72	212590010201	Rotisserie plate B		1
73	1122200101	Needle of rotisserie		7
74	212210011601	Tray		1
75	1122300201	Support for rotisserie		1
77	2120401101	Side catalytic liners		2
78	2126700303	Baffle		1

CDAC2902BG

Complete door