



C2902GM

Caple 90cm Touch Control Oven Gun Metal




Technical Manual



C2902GM

Caple 90cm Touch Control Oven Gun Metal





C2902GM

Caple 90cm Touch Control Oven Gun Metal

Item	Part Number	Description	Remark	Quantity
1	142101500201	Power cord		1
2	1421600101	Power box		1
3	2121603801	Back Panel		1
4	142090020101	Circulating fan motor		1
5	2125700101	Top heater plate		1
6	1920100226	Rear isolation cotton		1
7	1420700113	Lamp		2
8	1420500128	Top heater		1
9	2121400102	Top Panel		1
10	1420900143	Cooling fan		1
11	212670030401	Vent		1
12	1920100118	Upper isolation cotton		1
13	212540010301	Top and Bottom frame		2
14	2125500101	Synchronous motor plate		1
15	1420900305	Synchronous motor		1
16	2125600101	Plate for thermostat		1
17	1421200207	Thermostat 110°C		1
18	212520010101	Right frame		1
19	2121000103	Right panel		1
20	1220100102	Aluminium casing		2
21	212090160101	Cavity		1
22	2128400103	Rivet Nuts		2
23	1220100117	Fixing screws for side shelves		2
24	1420500304	Circle heater		1
25	1220100123	Heat shield studs		4
26	212030020101	Fan cover		1
27	1220100104	Nuts for fan cover		4
28	2126500301	Hinge bracket		2
29	21202002101	Door frame		1
30	1320600126	Plastic cushion for inner glass		1
31	1422100139	Timer		1
32	2124920001	Bracket for Control panel		1
36	CPC2902GM	Control Panel components	Timer box 1321500106	1
			GM decorative frame for control panel 21201016012	1
			Glass Panel 24021312W089001	1
37	1120100354	Inner glass		1
38	2127400702	Fixing plate for Middle Glass		2
39	1120100218	Middle Glass		1
40	212740190101	S.S. Door bracket		1
41	1123500207	Right buckle for door bracket		1
42	2127401803	Spring for glass bracket		2
44	1120400703	Outer hinge		2



C2902GM

Caple 90cm Touch Control Oven Gun Metal

Item	Part Number	Description	Remark	Quantity
45	OGC2902GM	Outer glass components	Left door bracket	1
			Outer glass 112010019615	1
			Right door bracket	1
			GM cladding 20021309405002	2
47	2126600301	Fixing plate for left outer door hinge assembly		1
48	1320600123	Plastic gasket for left door hinge bracket		1
49	112240031403	Handle		1
51	1320600124	Plastic gasket for right door hinge bracket		1
54	1123500208	Left buckle for door bracket		1
55	1320200105	Door Seal		1
56	1422100140	Power board for PCB		1
57	2127300108	Cavity support		1
58	2121100103	Left panel		1
59	1123900101	Holder		2
60	212530010501	Left frame		1
61	1420500216	Bottom Heater		1
62	2123900201	Fixing plate for bottom heater		1
63	2121700601	Clips for bottom heater		2
64	2121300104	Isolated plate		1
65	1121800107	Probe		1
66	2121800202	Bottom panel		1
67	1120500801	Side shelves		2
68	EB-67ECD6-L-06A/B	Full extension runner		2
69	1120500123	Big rack		2
70	1120500206	Small rack		1
71	1122600112	Rotisserie components		1
72	212590010101	Rotisserie plate A		2
72	212590010201	Rotisserie plate B		1
73	1122200101	Needle of rotisserie		7
74	212210011601	Tray		1
75	1122300201	Support for rotisserie		1
77	2120401101	Side catalytic liners		2
78	2126700303	Baffle		1

CDCC2902GM

Complete door



C2902GM

Caple 90cm Touch Control Oven Gun Metal

