




C3245

Caple Built in Double Oven




Technical Manual



C3245

Caple Built in Double Oven





C3245

Caple Built in Double Oven

Item	Part Number	Description	Additional Info	QTY
1	EB888RD-28	power cord		1
2	EB888RD-27	power box		1
3	EB888RD-20	rear cover		1
4	EB888RD-22	thermostat 145°C		1
5	EB56-109-A	bracket of convection motor		2
6	EB-56ECG-P8B22-02	lamp	Serial num pre ABE101731*****	2
6	EB-100ERC2-15	Halogen Lamp	Serial num after ABE101731*****	2
7	EB888RD-26	rear isolation cotton (top oven)		1
8	EB888RD-09	top heater(top oven)		1
9	EB56-41-06	motor (cooling fan)		1
10	EB888RD-19	top cover		1
11	EB56-115-B	cooling cover		1
12	EB56-116-B	separator(cooling cover)		1
13	EB56-31-01	thermostat (50°C)		2
14	EB56-114-B	top panel		1
15	EB888RD-25	top isolation cotton (top oven)		2
16	EB888RD-18	right side panel		1
17	EB56-31-02	Rivet nut		4
18	EB888RD-08-00	Inner cavity assembly(top oven)		1
19	EB888RD-11	Side Shelf(top oven)		2
20	EB5-04-02	big grill rack		2
21	EB888RD-03-00	frame assemble to inner cavity		1
22	EB888RD-05	right side frame		1
23	EB888RD-14	door seal		1
24	EB888RD-06	door frame(top oven)		1
25	EB888RD-10	Liquid expansion thermostat		1
26	FD-04-02	switch(four stalls)		1
27	EB56-31-03	#3 indicator		2
29	EB888RD-02	bottom plate of control panel		1
30	EB888RD-41	display		1
31	EB56-153-4A	timer bracket		1
28	EB888D3-8BC06	Control panel component	glass control panel	1
32			stainless Steel control panel	1
33	EB888RD-44	knob		4
34	SB-524-B	door bracket		2
35	EB888RD-13-06	middle glass(top oven)		1
36	EB888RD-13-02	Upper outer door component	266 right door bracket	1
38			outer door glass(top oven)	1
43			right door bracket	1
44			door braket platen	1



C3245

Caple Built in Double Oven

Item	Part Number	Description	Additional Info	QTY
37	EB888RD-38	door hinge		2
40	EB888RD-43	handle		2
41	EB40-304-A	right bracket for door hinge		2
42	EB40-303-A	left bracket for door hinge		2
45	EB888RD-13-07	inner glass(top oven)		1
46	EB57-633-1	Timer keys		6
47	EB56-122-A	control panel plug		3
48	FD-04-01	switch(four stalls)		1
49	142110010502	Liquid expansion thermostat		1
50	EB888RD-04	left side frame		1
51	EB56-05-03	fixing screws(side shelf)		4
52	EB888RD-12-00	Inner cavity assembly(bottom oven)		1
53	EB56-03-03	Side Shelf		2
54	EB57-512-1	circle heater		1
55	EB56-110-A	fan cover		1
56	EB888RD-36	door seal		1
57	EB888RD-07	door frame(bottom oven)		1
58	EB888RD-15-05	inner glass(bottom oven)		1
59	EB888RD-15-04	middle glass(bottom oven)		1
39	EB56-135-A	Bottom outer door component	Door decorated plate	1
44			door braket platen	1
60			440 right door bracket	1
61			Outer glass	1
63			440 left door bracket	1
62	EB56-31-06	outer door hinge assembly		2
64	EB56-162-2A	Food tray		2
65	EB56-103-A	bottom heater plate		1
66	EB888RD-16	bottom plate		1
67	EB56-166-A	top isolation cotton		1
68	EB56-165-A	rear isolation cotton		1
69	EB888RD-17	left side panel		1
70	EB57-546-1	handle		2
71	EB56-41-05	circulating fan motor		1
72	EB56-31-07	thermostat 110°C		1
73	EB56-09-01	small grill rack		1
74	EB56-154-A	upper heater		1
75	EB40-220-A	bottom heater		1
76	EB56-31-08	15x8xΦ9 Silicone		1
77	EB56-195-A	tray handle		1

EB888RD-UD Complete door

EB888RD-UD Complete door

