



C4246

Caple Built Under Double Fan Oven Stainless Steel




Technical Manual



C4246

Caple Built Under Double Fan Oven Stainless Steel





C4246

Caple Built Under Double Fan Oven Stainless Steel

Item	Part Number	Description	Additional Info	Quantity
1	EB888RD-28	Power cord		1
2	EB888RD-27	Power box		1
3	EB720RD-09	Rear cover		1
4	EB56-31-09	Thermostat 130°C		2
5	EB56-109-A	Bracket of convection motor		1
6	1420700113	Lamp		2
7	EB888RD-26	Rear isolation cotton (upper oven)		1
8	EB888RD-09	Top heater(upper oven)		1
9	EB56-41-06	Motor (cooling fan)		1
10	EB888RD-19	Top cover		1
11	EB56-115-B	Cooling cover		1
12	EB56-116-B	Separator(cooling cover)		1
13	EB56-31-01	Thermostat (50°C)		2
14	EB56-114-B	Top panel		1
15	EB888RD-25	Top isolation cotton (upper oven)		2
16	EB720RD-08	Right side panel		1
17	EB56-31-02	Rivet nut		4
18	EB888RD-08-00	Inner cavity assembly(upper oven)		1
19	EB888RD-11	Side Shelf(upper oven)		2
20	EB5-04-02	Big grill rack		2
21	EB720RD-01-00	Frame assemble to inner cavity		1
22	EB720RD-03	Right side frame		1
23	1320200802	Door seal		2
24	EB888RD-06	Door frame(upper oven)		1
25	EB888RD-10	Liquid expansion thermostat		1
26	FD-08-01	Switch(eight stalls)		1



C4246

Caple Built Under Double Fan Oven Stainless Steel

Item	Part Number	Description	Additional Info	Quantity
27	EB56-31-03	#3 indicator		2
28	CPAC4246	Control panel assembly	Glass panel	1
			Stainless steel frame	1
29	EB888RD-02	Bottom plate of control panel		1
30	60110522W089002	Timer		1
31	EB56-153-4A	Timer bracket		1
33	EB888RD-44	Knob		4
34	SB-524-B	Door bracket		2
35	EB888RD-13-06	Middle glass(upper oven)		1
36	CLEB888RD-UD-OD	Outer glass assembly for upper door	266 right door bracket	1
			Outer door glass(top oven)	1
			Right door bracket	1
			Door bracket platen	2
37	EB888RD-38	Door hinge		4
38	CLEB888RD-UD-OD	Outer glass assembly for bottom door	Door decorated plate	1
			Door bracket platen	1
			Outer door glass(top oven)	1
			277 right door bracket	1
			277 left door bracket	1
39	EB888RD-43	Handle		2
41	EB40-304-A	Right bracket for door hinge		2
42	EB40-303-A	Left bracket for door hinge		2
45	EB888RD-13-07	Inner glass(upper oven)		1
47	EB56-122-A	Control panel plug		3
48	FD-04-01	Switch(eight stalls)		1
49	EB56-31-04	Liquid expansion thermostat		1
50	EB720RD-06-00	Inner cavity assembly(bottom oven)		1



C4246

Caple Built Under Double Fan Oven Stainless Steel

Item	Part Number	Description	Additional Info	Quantity
51	EB720RD-02	Left side frame		1
52	EB40-222-A	Side Shelf		2
53	EB40-221-A	Circle heater		1
54	EB40-206-A	Fan cover		1
56	EB720RD-05	Door frame(bottom oven)		1
57	EB720RD-11-05	Middle glass(bottom oven)		1
60	EB720RD-11-04	Inner glass(bottom oven)		1
61	EB56-162-2A	Food tray		2
62	EB56-103-A	Bottom heater plate		2
63	EB888RD-16	Bottom plate		1
64	EB-68ECD3-10	Heat shield		1
65	EB40-220-A	Bottom heater		2
66	EB56-05-03	Fixing screws(side shelf)		4
67	EB720RD-12	Rear isolation cotton (bottom oven)		1
68	EB40-205-A	Bracket of convection motor		1
69	EB720RD-07	Left side panel		1
70	EB57-546-1	Handle		2
71	142090021901	Circulating fan		1
73	EB56-09-01	Small grill rack		1
74	EB40-219-A	Upper heater		1
75	EB56-31-08	15x8xΦ9 rubber		2
76	EB56-195-A	Tray handle		1

CLEB888RD-UD Complete top door

CLEB720RD-BD Complete bottom door

C4246 Circuit Schematics

