



WD140SS

Caple Warming Drawer 140mm Push/Pull Sense Stainless Steel




Technical Manual



WD140SS

Caple Warming Drawer 140mm Push/Pull Sense Stainless Steel





WD140SS

Caple Warming Drawer 140mm Push/Pull Sense Stainless Steel

Item	Part Number	Description	Additional Info	Quantity
1	2170500201	Top Cover 1		1
2	2170100101	Top Cover 2		1
3	1350600302	PVC Pad		1
4	1150600105	Drawer bottom assembly		1
5	2170500103	Fan cover		1
6	WD-26-A	Fan cover (Grille)		1
7	2170800201	Fixing plate for thermostat		1
8	1450700101	Thermal protector		1
9	1450100101	Heating element		1
10	1450500114	Power Cord		1
11	1421600101	Power box		1
12	2170900105	Fan box		1
13	115020010101	Runners		1
14	2170400103	Side Panel-Left		1
15	1450600101	Fan		1
16	2170800101	Fixing plate for heating element		1
17	1450300101	Thermostat 75°C		1
18	2171200205	Control Panel		1
19	132010015101	Knob		1
20	1450200201	Button Switch		1
21	1150800101	Push-pop device		1
22	2171600101	Bracket for push-pop device		1
23	1150900101	Push-pop device buckle		1
24	2171600102	Bracket for push-pop device buckle		1
25	2170200102	Bottom plate		1
26	1350700101	Light guide		1
27	1350600201	Fixing for light guide		1
28	2171700101	Back door frame		1
29	SSP140WD	Glass panel component	Bottom fixing plate for drawer	1
30			Glass Panel	1
31			Sense Steel Panel	1
32			Top fixing plate for drawer	1
34	2170400104	Side Panel-Right		1
35	2171100101	Top frame		1