




C4071G

Caple 76cm gas hob




Technical Manual



C4071G

Caple 76cm gas hob





C4071G

Caple 76cm gas hob

Item	Part Number	Description	Quantity
1	000C400021	Middle pan support	1
2	000C400022	Right pan support	1
3	000C400003	1.75 KW burner distributor and lid	2
4	000C400008	4.0 KW burner distributor and lid	1
5	000C400023	SS top panel assembly	1
6	000C400024	Left pan support	1
7	000C400025	3.0 KW burner distributor and lid	1
8	000C400004	1.0 KW burner distributor and lid	1
9	000C400006	Knob	5
10	000C400007	Knob sealing rubber	5
11	000C400026	Small support	2
12	000C400027	1.75KW burner basic assembly	1
13	000C400028	1.75KW burner basic assembly	1
14	000C400029	Large support	1
15	000C400030	3.0 KW burner basic assembly	1
16	000C400031	1.0 KW burner basic assembly	1
17	000C400010	4.0 KW burner basic assembly	1
18	000C400032	Bottom panel	1
19	000C400018	Valve for 1.0 KW burner	1
20	000C400033	Valve for 3.0 KW burner	1
21	000C400020	Valve for 4.0 KW burner	1
22	000C400019	Valve for 1.75 KW burner	1
23	000C400016	Terminal box and power cord	1
24	000C400034	Ignitor	1
25	000C400035	Gas inlet tube assembly	1
26	000C400019	Valve for 1.75 KW burner	1
27	000C400050	Fixing hook with screw	4
28	000C400052	Sealing strip	1
29-A	000C400054-A	Electrode for bottom-right burner	1
29-B	000C400054-B	Electrode for top-right burner	1
29-C	000C400054-C	Electrode for bottom-left burner	1
29-D	000C400054-D	Electrode for top-left burner	1
29-E	000C400054-E	Electrode for middle burner	1
30-A	000C400055-A	Thermocouple for bottom-right burner	1
30-B	000C400055-B	Thermocouple for top-right burner	1
30-C	000C400055-C	Thermocouple for bottom-left burner	1
30-D	000C400055-D	Thermocouple for top-left burner	1
30-E	000C400055-E	Thermocouple for middle burner	1